

WELL LOG and REPORT

For method of making report, refer to bulletin entitled "Well Construction Report," 7-5-1939.

In this column indicate the kind of casing, liner, shoe and other accessories used.

WELL DIAGRAM
Use a red line to show casing or liner pipe. Use black for drill or borehole.

In this column state the kind of formations penetrated, their thickness in feet and if water bearing.

Record of **FINAL** Pumping test

six in
Galvanized 20 gage tubing increased in Portland Cement grout

Inches Diameter											Depth
2	3	4	5	6	8	10	12	14	16	18	
											25
											25 ft
											50
											75
											100
											150
											200
											400
											800
											1200

20 ft top Soil

2 20 ft lime rock
120 ft sandrock
Balance Blue shale
400 ft depth.

Duration of test
Hours *4 hrs*

Pumping rate
G.P.M. *300 gal Hour*

Depth of pump in well. Ft. *396 ft*

Standing water-level (from surface)
Ft. *260 ft*

Water-level when pumping Ft. *260*

Water. End of test.
Clear
Cloudy _____
Turbid _____

Was the well sterilized?
Yes No _____

To which laboratory was sample sent?
state
Date *aug 25, 41*

Was the well sealed on completion?
Yes No _____

How high did you leave the casing-pipe above grade?
1 ft

Well was completed
Date *March 29*
1941

Well Driller
E. S. Centers
Signature

Draw the diagram to show the right half only